Environmental Engineering and Management Journal

April 2015, Vol.14, No. 4, 879-886 http://omicron.ch.tuiasi.ro/EEMJ/



"Gheorghe Asachi" Technical University of lasi, Romania



## NOVEL ELECTROKINETIC REMEDIATION SYSTEM - BORON DOPED DIAMOND (EKR-BDD) PROCESS FOR THE DESTRUCTION OF POLYAROMATIC HYDROCARBONS (PAHs) IN LIQUID PHASE

Alejandro Medel<sup>1\*</sup>, Diana Patiño<sup>1</sup>, Erika Méndez<sup>1,2</sup>, Yunny Meas<sup>1</sup>, Luis Godínez<sup>1</sup>, Juan Manríquez<sup>1</sup>, Francisco Rodríguez<sup>1</sup>, Adrián Rodríguez<sup>1</sup>, Erika Bustos<sup>2\*</sup>

<sup>1</sup>Center for Research and Technological Development in Electrochemistry. Technological Park Querétaro S/N, Sanfandila, Pedro Escobedo, Querétaro P.C. 76730 <sup>2</sup>Autonomous University of Puebla, Chemistry Center of the ICUAP, University City. Bldg. 103H. Puebla, Puebla, Mexico P.C. 72570

## Abstract

This research evaluated two electrokinetic remediation systems (EKR) for separating phenanthrene from bentonite and its electrochemical destruction by using a Boron Doped Diamond (BDD) electrode. The effect of the electrochemical potential for the oxidation of phenanthrene in liquid phase with Ti/BDD was analyzed by Normal Pulse Voltammetry and Hydroxyl Radical (<sup>•</sup>OH) analysis using the *Spin Trapping Technique*. The results showed that 70% of phenanthrene was removed from bentonite through EKR by applying 20 mA for 4 h in alkaline conditions, and that phenanthrene in solution was 100% degraded with Ti/BDD by applying 2.3 V vs Hg|Hg<sub>2</sub>SO<sub>4</sub>, for 2.5 h. These results demonstrate the potential application of the electrochemical technology in treating soils contaminated with highly toxic compounds, such as Polyaromatic Hydrocarbons (PAHs) and their final destruction using the EKR-BDD process.

Key words: diamond, hydroxyl radical, PAHs, soil

Received: January, 2014; Revised final: August, 2014; Accepted: August, 2014

<sup>\*</sup> Authors to whom all correspondence should be addressed: e-mail: alejandromedelreyes@gmail.com, ebustos@cideteq.mx; Phone: +52 442 2 11 60 59; Fax: + 52 442 2 11 60 01